

DUNE^{4WD}

*Thankyou for purchasing a Dune 4wd Deluxe gazebo.
We recommend you set up this gazebo after purchase to ensure all the parts are present
and to familiarise yourself with the assembly/ dissassembly process.
Should you have any questions, please contact a team member at your local Anaconda store.*

WARNING - PLEASE READ BEFORE USE

- This gazebo is designed as a portable and temporary structure and should not be used as a permanent structure.
- Do not leave the gazebo unattended in heavy rain. During periods of heavy rain, ensure that water does not collect on the canopy as the weight of the water can lead to breakage and cause the gazebo to collapse.
- Always secure the gazebo firmly to the ground, ensuring all pegs and guy ropes are utilised and remain firm.
- In times of heavy rain or strong winds, ensure the canopy is removed to avoid damaging the gazebo.
- Do not fold up the gazebo with the canopy still attached. The canopy can be damaged if caught in the scissor action struts.
- For safety precautions, it is recommended that two people lift this gazebo.
- Do not drop the gazebo on the ground.

ASSEMBLY INSTRUCTIONS

1. Pull each corner of frame in outward direction to expand gazebo frame.
2. At each of the four corners slide corner frame upwards until you hear audible click and corner is engaged to its maximum height
3. Place the canopy over the top of frame. Align canopy corners with frame corners. Secure by matching Velcro® of canopy to frame corners. Additionally, attach the hook and loop straps on the underside of the canopy to the frame, to ensure the canopy is securely fastened.
4. The adjustable legs offer multiple height positions. Tilt one side of frame upward, extend lower leg section until it clicks into place. Repeat on all legs.
5. Using pegs provided, secure each gazebo foot firmly in to the ground. If ground is soft or sandy, longer pegs or weight should be used.
6. For disassembly remove pegs, Unlock all 4 legs. Unlock each frame corner. Remove canopy. Walk each frame corner into the centre.

CARE INSTRUCTIONS

- Wipe down all metal surfaces with fresh water after use
- To remove any marks, use sponge with mild detergent only
- Allow to dry thoroughly before storing
- Never pack away gazebo when it is damp, dirty or wet.

MATERIALS

Frame: steel with plastics components

Canopy: polyester

WARRANTY

This product is guaranteed to be free from defects in workmanship & materials for a period of 12 months from date of purchase. The product will be replaced or refunded for a major failure. The product will be repaired or replaced at our discretion, should the product fail to be of an acceptable quality and failure is not considered a major failure.

Warranty will not apply if the product (a) is damaged through misuse (including failure to maintain), neglect, accident or ordinary wear and tear (including rust, corrosion, normal fading, weathering staining, discolouration, scratching or chipping) (b) is damaged through exposure to heat (c) is used commercially (d) has not been used or installed in accordance with any applicable instructions or (e) has been modified, repaired or tampered with or by the purchaser or an unauthorised service person.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of an acceptable quality and the failure does not amount to a major failure.

To claim this warranty, please take this product to the Anaconda where you purchased it. You will need your receipt or other proof of purchase. Additional information may be requested of you to process your claim. Should you not be able to provide proof of purchase with a receipt a bank or credit statement, and identification showing your name, address and signature may be required to process your claim.

Any expense relation to the return of the product to the store will be at the expense of the customer. For online purchases, please contact us to arrange where and how to return the product.

To obtain compensation, you will need to provide documentary evidence of the loss or damages suffered, and documentary evidence that such loss or damage was a reasonably foreseeable consequence of a failure. Such evidence may include photographs, statutory declarations, receipts, reports (e.g. From the doctor), depending on the loss of damage.

The benefits given by this warranty are in addition to other rights and remedies under the Australian Consumer Law in the relation to the goods and services to which this warranty relates.

Warranty excludes consumable replacement/ serviceable parts (where applicable to the product) as detailed in the product instruction manual or packaging, which are available for purchase.

The warranty is provided by:
Anaconda Group Pty Ltd (ABN 53 955 173 782)
Level 6, 111 Cecil Street, South Melbourne, VIC, 3205
www.anacondastores.com
PH: 1300 558 990

Designed & imported by:
Anaconda Group Pty Ltd (ABN 53 955 173 782)
Level 6, 111 Cecil Street, South Melbourne, VIC, 3205
Made in China.