

DUNE^{4WD}



ULTIMATE GAZEBO

ASSEMBLY INSTRUCTIONS

THIS RECREATIONAL PRODUCT REQUIRES TWO PEOPLE TO ASSEMBLE.

The gazebo needs to be staked and guy roped and in case of heavy winds/ severe storms it should be lowered.

* Do not drop the gazebo bag. Do not bounce the gazebo bag on its end to remove the gazebo, as these actions may damage the frame ends.

Step 1: Extend the Gazebo Frame

- a) Select a smooth, level site for your gazebo.
- b) With two people standing at diagonal corners of the structure, grab the leg on that corner and pull it towards you, unfolding the frame enough to allow you to comfortably drape the canopy over the frame.

Step 2: Set Up the Gazebo

- a) Drape the roof over the frame and attach the touch tape found on the corners of the canopy to the corners of the frame.
- b) After attaching each corner of the roof to the frame, slide the safety lock mechanisms located on the upper portion of each leg towards the top corners of the frame until they lock into place. This will ensure the frame is fully extended

Step 3: Stake the Gazebo

Secure the gazebo by driving nail stakes through the holes located on the metal base of each leg.

Step 4: Adjust the Height

Adjust the height by sliding the legs upwards until the safety mechanism locks into place.

Note: Keep away from open flame and take down in windy conditions